
TC-105 Timber & Profile Cutter
Schneidegerät für Holz und Profile




Overview / *Übersicht*


You can use the cutter right out of the box as cutter blade is already mounted on the cutting arm. There are 4 screws included in case you need to fix your cutter on a wooden board or workbench for better stability. TC-105 Cutter uses standard cutter blades which can be found at any stationary, hardware shop, or even a grocery.


Sie können das Schneidegerät direkt nach dem Auspacken verwenden, die Schneideklinge bereits vormontiert ist. Wenn Sie das Schneidegerät auf einer Werkbank oder einem Holzbrett fixieren wollen, liegen für diesen Zweck vier Schrauben bei. Das TC-105 Schneidegerät verwendet handelsübliche Klingen, die Sie z.B. in jedem Baumarkt erwerben können.


Specifications:
Board Size: 220 X 163 mm
Blades: 17-19 mm scored (snap-off, break-off) standard cutter blades.
Cutting height: Up to 8 mm depending on the width and hardness of timber or profile.
Cutting width: Up to 30 mm depending of the height and hardness of timber or profile.
Materials to cut: Soft woods, styrene, plastics.

Produktdetails:
Gesamtgröße: 220 X 163 mm
Messerklingen: 17-19 mm Standard-Messerklingen, abbrechbar.
Schnitthöhe: bis zu 8 mm, abhängig von Breite und Härte des Holzes oder des Profils.
Schnittbreite: bis zu 30 mm, abhängig von Breite und Härte des Holzes oder des Profils.
Bearbeitbares Material: Weichholz, Kunststoff, Styrene.


Fixing the blades. *Befestigung der Messer.*


Cutting by using the sizer. *Schneiden mit Hilfe des Maßstabs.*


Cutting by using the angle stop.
Schneiden mit Hilfe des Winkelanschlags.


Cutting at 45 degree by using the board itself.
Schneiden im 45 Grad-Winkel mit dem Schneidegerät selbst.